











事前准备工具: 手套 (为防止安装过程中受伤请务必佩戴)
 用意する工具: 手袋 (取り付け時の怪我防止のため、必ず着用してください。)
 Pre-prepared tools: Gloves (please wear them to prevent injuries during installation)




4




5




6




7




8




9




10




11




面板高度调节方法
天板の高さ調節方法
Method for Adjusting the Height of the Table Top



面板角度调节方法
天板の角度調節方法
Method for Adjusting the Angle of the Table Top



面板角度调节方法
天板の角度調節方法
Method for Adjusting the Angle of the Table Top



⚠ 注意事项 ⚠

- 移动本产品时, 为避免倾倒请将面板降至最低再移动。
- 调节面板高度时, 请注意桌板下是否有人或物阻碍。
- 升降高度时请勿触碰支柱下侧。请特别注意勿让儿童触碰。
- 请勿倚靠本产品或者坐于面板上。
- 请勿在本产品上放置加热后的锅具或容器等物品。
- 请避免在阳光直射/高温/低温/过度湿润/过度干燥等极端环境使用本产品。
- 请在室内平坦地面上使用本产品。
- 有明显脏污时, 可用少许中性清洁剂清洁。
- 请勿拆解、改造、擅自维修本产品。
- 请将螺丝/旋钮等旋紧后再使用本产品。

- 请勿在面板上放置有物品时移动本产品。
- 请勿在本产品标注的用途以外使用。
- 请勿拆除部件并在部件不齐全时使用本产品。
- 请勿将超过标注承重的物品放置于本产品上使用。

⚠ 注意事項 ⚠

- 製品を移動させる際には、天板を最下位部に下げてから移動させてください。
- 天板の高さを下げる際には、天板の下に人や物がないか確認してから下げてください。
- 昇降中は支柱の下側に触れないようにしてください。特にお子様には触らせないように十分に注意してください。
- 製品の上に腰掛けたり、乗らないでください。
- 加熱した鍋、湯沸かし器、アイロン等を直接置かないでください。
- 直射日光またはストーブの熱、クーラーの風が当たる場所や高温、湿気及び乾燥の著しい場所を避けてください。
- 必ず屋内の平坦で安定した場所で使用してください。
- 著しい汚れを落とす場合は、薄めた中性洗剤を使用してください。
- 分解、改造、修理をしないでください。
- ボルト・ネジ類がゆるんだまま使用しないでください。

- 物を載せた状態で移動させないでください。
- 用途以外で使用しないでください。
- 部品を外したり、部品が外れたまま使用しないでください。
- 耐荷重以上の重さの物や、積み重ね禁止の物を載せないでください。

⚠ CAUTION ⚠

- When moving this product, to avoid tipping, please lower the table top to the lowest position before moving.
- When adjusting the table top height, make sure there are no people or objects under the table top that may be obstructed.
- Do not touch the bottom of the support column while adjusting the height. Please especially keep children away from it.
- Do not lean on or sit on the table top of this product.
- Do not place heated pots or containers on this product.
- Avoid using this product in extreme environments, such as direct sunlight, high temperatures, low temperatures, excessive humidity, or extreme dryness.
- Use this product only on a flat indoor surface.
- Do not move the product when there are items placed on the table top.
- If there is visible dirt, you may clean it with a small amount of neutral detergent.
- Do not use this product for purposes other than those specified.
- Do not disassemble, modify, or repair the product yourself.
- Do not use the product if any parts are missing or removed.
- Make sure screws, knobs, and other fasteners are securely tightened before use.
- Do not place items on this product that exceed the maximum weight capacity indicated.