

# Trackball Mouse

## Manual/取扱説明書/使用说明书



### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### 1. Opening

Thank you for purchasing this Trackball Mouse.

### 2. Caution

- The company is not liable for any damages, such as live motion defects, data loss, etc., caused by using this product or software.
- This product is intended for use in general workplaces and homes. The company does not assume responsibility in the event of damages caused by using in any other places.
- Refrain from using in environments where medical instruments and systems directly or indirectly related to human life are required, and where a high level of safety and responsibility is required.
- Refrain from using directly or indirectly with equipment and computer systems in which a high level of safety and responsibility are required.
- Do not use this product on airplanes as it may interfere with the airplane communication system.
- Please consult your doctor before using this product if you use a pacemaker or other medical device.

### 3. Warnings Regarding Health

Operating the mouse, trackball, and keyboard for long periods of time can lead to pain or numbness in hands, arms, neck, shoulders, etc. Serious damage may be incurred if such use is repeated. If you feel pain or numbness while operating the mouse or keyboard, stop using it immediately and consult a doctor if necessary. Take regular breaks from daily computer work to avoid strain on hands, arms, neck, shoulders, etc.

### 4. Specifications

Interface	USB 3.2/3.1/3.0/2.0/1.1
Connector Shape	USB A
Resolution	600-800-1200-1600 DPI
Reading Method	Optical sensor system
Buttons	2 buttons, 2 side buttons, wheel button (scroll), count switch button
Size/Weight	W103.1×D170.7×H54.8mm; approx.212g
Cable Length	Approx.1.8m

### 5. Compatible Models

Windows (DOS/V) PC  
Apple Mac series  
Chrome OS PC  
\*Models with a USB A port.

### 6. Compatible OS

Windows 10-8.1-8  
macOS 12, 11, 10.13~10.15  
ChromeOS

### 4.仕様

インターフェース	USB HID仕様Ver.1.1準拠 ※USB3.2/3.1/3.0/2.0インターフェースでも使用になれます。
コネクタ形状	USB Aコネクタ
分解能	600・800・1200・1600count/inch
読み取り方式	光学センサー方式
ボタン	左右ボタン、2サイドボタン、ホイール(スクロール)ボタン、カウント切替ボタン
サイズ・重量	W103.1×D170.7×H54.8mm/約212g
ケーブル長	約1.8m

### 5.対応機種

Windows搭載(DOS/V)パソコン  
Apple Macシリーズ  
Chrome OS搭載パソコン  
※USB Aポート搭載機種

### 6.対応 OS

Windows 10-8.1-8  
macOS 12, 11, 10.13~10.15  
ChromeOS

### 4.规格参数

适用规格	USB 3.2/3.1/3.0/2.0/1.1
接口形状	USB A型
分辨率	600-800-1200-1600 DPI
读取方式	光学传感
按键	左键、右键、侧键 x2、滚轮按键、DPI 切换键
尺寸·重量	约 W103.1×D170.7×H54.8mm-212g
线长	约 1.8m


### 5.适用设备

搭载 Windows (DOS/V) 的电脑  
Apple Mac 系列  
搭载 Chrome OS 的电脑  
※适用带有 USB A 接口的设备


### 6.适用 OS

Windows 10-8.1-8  
macOS 12, 11, 10.13~10.15  
ChromeOS

### 7.Name of Parts



### 7.各部の名称



### 8. How to Connect the Trackball

- \*Warning: It is recommended that other apps are closed before connecting the trackball mouse.
- ①Turn on the PC and wait until OS starts up completely.
- ②Connect this product to the USB port of the computer.
- ③Hardware detection will start automatically and a wizard will launch to update the device driver. (installation is automatically completed for Mac and Chrome OS products)

### 9. Set Deceleration Mode

- Set to deceleration mode to slow down the cursor speed.
- How to set:Press and hold the right button and the forward button simultaneously for at least 3 seconds. The LED will blink and enter the deceleration mode.
- How to cancel:Press and hold the right button and the back button simultaneously for at least 3 seconds. The LED will blink and the deceleration mode will be canceled.


### 8.トラックボールの接続

- ※注意:トラックボールを接続する前に他のアプリケーション等を終了させておくことをお薦めします。
- ①パソコンの電源を入れ、OSを完全に起動します。
- ②本製品をパソコンのUSBポートに接続します。
- ③自動的ハードウェアの検知が始まり、デバイスドライバーを更新するためのウィザードが起動します。(Mac、Chrome OSの場合は自動的にインストールが完了します)

### 9.減速モードの設定

- 減速モードに設定するとカーソルスピードを遅くすることができます。
- 設定方法:右ボタンと進むボタンを同時に3秒以上長押しします。お知らせLEDが点滅し、減速モードに入ります。
- 解除方法:右ボタンと戻るボタンを同時に3秒以上長押しします。お知らせLEDが点滅し、減速モードが解除されます。

### 7.部件说明



### 8.鼠标连接

- ※注意: 在连接轨迹球鼠标之前请先关闭其他应用程序。
- ①打开电脑电源, 启动操作系统。
- ②将本产品连接到电脑的 USB 接口。
- ③开始自动检测硬件, 并启动设备驱动程序更新向导。(Mac、Chrome OS 环境下自动完成安装)

### 9.设置减速模式

- 设置为减速模式时, 可以减慢光标速度。
- 设置方法: 同时长按右键与前进键 3 秒以上, LED 闪烁, 进入减速模式。
- 取消方法: 同时长按右键与后退键 3 秒以上, LED 闪烁, 返回普通模式。

### 10. Customize Buttons (for Windows Only)

- To use the button custom function, you need to install a driver from our website.
- \* Only Windows is available.
- [Driver installation method]  
①Access "https://www.sanwa.com/download/tbx.exe"  
②Click to download and save the file.  
③Confirm the agreement on the software specification license, click "Yes" and start the download.
- ④Follow the instructions and click "Next" and "Install".  
\* If you have any problems during installation or use, please contact us.  
⑤The driver is installed. Click "Finish".

### 11. Troubleshooting

- Q.The trackball (cursor) doesn't move.  
A.Please check if this product is correctly connected to the USB port. (See "8. How to Connect the Trackball")

- Q.The cursor or scroll movement is not smooth.  
A.Remove the ball and clean it.

### 10.ボタン割り当て機能を使用する(Windowsのみ)

- ボタン割り当て機能を使用するには、弊社WEBサイトよりドライバーをインストールする必要があります。※Windowsのみ使用可能です。
- 【ドライバーインストール方法】  
①https://direct.sanwa.co.jp/ItemPage/400-MATB137にアクセスします。  
②ページ内のドライバーインストールバナーをクリックし、zipファイルを保存します。  
③[SANWA Trackball Soft-X.exe]を開きます。  
④指示に従い、「次へ」「インストール」をクリックします。  
⑤ドライバーがインストールされます。「完了」をクリックします。

ソフトの正しい使用方法、保証規定は[https://direct.sanwa.co.jp/ItemPage/400-MATB137]に掲載のダウンロード版取扱説明書をご確認ください。

### 11.「故障かな...」と思ったら

- Q.トラックボール(カーソル)が動かない。  
A. 本製品が正しくUSBポートに接続されているか確認してください。 ("8.トラックボールの接続"参照)
- Q. カーソルやスクロールの動きがスムーズでない。  
A. ボールを外してクリーニングしてください。

### 10. 按键自定义功能 (仅适用于 Windows)

- 如果要使用按键自定义功能, 您需要从我司网站安装驱动程序。
- ※仅适用于 Windows。
- 【驱动程序安装方法】  
①请访问: "https://www.sanwa.com/download/tbx.exe"  
②点击下载按钮。  
③显示有关软件规格许可证的协议, 确认后点击 "是" 并开始下载。  
④打开下载好的软件进入安装向导并点击安装。  
\* 在安装或使用过程中如遇任何问题, 请与我司取得联系。  
⑤安装完成后点击 "完成"。

### 11. 故障诊断

- Q. 无法移动鼠标 (指针)。  
A. 请确认本产品是否正确连接到 USB 接口。(请参照第 8 项)

- Q. 指针和滚轮使用不灵活。  
A. 取出轨迹球并进行清洁。

### 12. Warranty Term

1 year

### 13. Inquiries

EN: support-en@sanwa.com

### 12. 保証書

保証書	サンワサプライ株式会社
型番: 400-MATB137	シリアルナンバー:
お客様・お名前・ご住所・TEL	
販売店名・住所・TEL	
担当者名	保証期間 1年   お買い上げ年月日 年 月 日

### サンワサプライ株式会社

サンワダイレクト / 〒7700-0825 岡山県岡山市北区田町1-10-1  
TEL.086-223-5680 FAX.086-235-2381

### 12. 保修期限

1年

### 13. 产品咨询

CN: support-cn@sanwa.com