






more into


































- 请勿倚靠本产品或者坐于面板上。
 请勿在本产品之放置加热后的锅具或容器等物品。
 请这位在阳光直射/高温/低温/过度逻测/过度干燥等极端环境使用本产品。
 请充宝的开设地面上使用本产品。
 有可显能污时,可用少许中性清洁剂清洁。
 请勿拆解,改造、擅自帐修本产品。
 请对东麓/捉田转应联后再使用本产品。
 请勿在面板上放置有物品时移动本产品。
 请勿在面板上放置有物品时移动本产品。
 请勿在面板上放置有物品时移动本产品。
 请勿有面板上放置有物品时移动本产品。
 请勿有临产品标注的阳波以外使用。
 请勿将超过标注承重的物品放置于本产品上使用。

▲ 注意事項 ▲



- Do not lean on or sit on the table top of this product.
- Do not lean on or sit on the table top of this product.
 Do not place heated pots or containers on this product.
 Avoid using this product in extreme environments, such as direct sunlight, high temperatures, low temperatures, excessive humidity, or extreme dryness.
 Use this product only on a flat indoor surface.
 Do not move the product when there are items placed on the table top.
 If there is visible dirt, you may clean it with a small amount of neutral detergent.
 Do not use this product for purposes other than those specified.
 Do not disassemble, modify, or repair the product yourself.
 Do not use the product if any parts are missing or removed.
 Make sure screws, knobs, and other fasteners are securely tightened before use.
 Do not place items on this product that exceed the maximum weight capacity indicated.